



FOR THE LOVE OF SEWING



Decorator's Choice

Make your own personal design statement with the Decorator's Choice. Specifically designed with the decorator in mind, this sewing machine includes a diverse selection of stitches, feet and innovative features to complete décor projects in any style effortlessly.

Advanced Features



Advanced Needle Threader
Threading a needle has never been easier than with this innovative threader. With just a few simple motions, your needle is threaded and ready to use - it's so easy, you can do it with one hand!



Quick-Set, Top-Loading Bobbin
Avoid the struggle of changing your bobbin with the Quick-Set feature. Simply drop your bobbin in the machine, pull your threads through the slot, and let your machine do the rest of the work.


Convenient Sewing Features

- Quick-Set, Top-Loading bobbin
- Quick-Set bobbin winder
- Automatic needle threader
- Start/stop button
- Hands-free presser foot lift
- Programmable needle up/down
- Built-in programmable reinforcement stitch
- Automatic thread cutter
- Drop feed
- Free arm
- Easy to read stitch chart



- **Built-in Accessory Storage**
You'll never run out of choices for new machine accessories, and now you'll never run out of room to store them! Keep your accessories organized and at your fingertips with this built-in storage unit.

Highlight Features



- 178 Built-in stitches
- 67 Utility stitches with 10 one-step buttonhole styles
- 40 Decorative stitches
- 5 Cross stitches
- 16 Satin stitches
- 11 Decorative satin stitches
- 39 Combinable Utility stitches
- 3 Built-in upper case alphabets

Included Accessories

- 13 Snap-on feet
- Buttonhole
- Overcasting
- Monogramming
- Zipper
- Zigzag
- Blind stitch
- Button fitting
- Walking
- Quilting
- Stitch guide
- Nonstick
- Open toe



Quick-Set Bobbin Winder
Choice machines take all of the hassle out of sewing - including winding your bobbins! The winder seat holds the thread in place and stops automatically when the bobbin is full.



- **Hard case**
- **Push Button Features**
With a suite of push button features, your sewing projects have never been easier to complete. Position the needle up or down, reinforce any stitch with the reverse sewing button, or sew without a foot control using the start/stop button.